


---

## ACCESSING YOUR MAILBOX FROM OUTSIDE THE COMPANY:

- Enter the NuPoint Messenger system access number.
- Enter your mailbox number followed by the  key.
- Enter your passcode.

You're now at the main menu  
(shown inside)  
and are ready to begin messaging!



© 2002, Mitel Networks Corporation.  
NuPoint Messenger, NuPoint Voice, NuPoint  
Fax, NuPoint Agent are trademarks of Mitel  
Networks Corporation. All rights reserved.  
Printed in Canada.

MKG PN 50002392 Rev. A

ENG PN 57003913 Rev. A

MITEL  
NuPoint  
*Messenger*™

---

## Competitive Telephone User Interface (TUI)

# MAIN MENU


## PLAY MESSAGE

WHILE PLAYING:

- 1 Rewind
- 2 ABC Pause/Restart
- 3 DEF Fast Forward
- 5 JKL Date & Time
- 0 0 Attendant
- # Skip to Next Message
- 3 3 Skip Message
- 9 WXYZ Exit to Main Menu
- 0 Online Help

AFTER PLAYING:

- 1 Play Next Message
- 4 GHI Replay
- 5 JKL Date & Time
- 6 MNO Give
- 7 PQRS Discard Message
- 7 PQRS 9 WXYZ Discard Message & Exit to Main Menu
- 8 TUV Reply
- 9 WXYZ Save
- 9 WXYZ 9 WXYZ Save & Exit to Main Menu
- 0 Online Help
- 0 0 Attendant



## MAKE MESSAGE

- 7 PQRS Review
- 3 DEF Discard
- 2 ABC Append
- 5 JKL Leave a Fax
- 9 WXYZ Exit to Main Menu
- 6 MNO Message Addressing
- 2 ABC Confidential
- 7 PQRS Receipt request
- 8 TUV Urgent
- 3 DEF Future delivery
- 9 Exit options

## USER OPTIONS

- 4 GHI Change Greeting
- 6 MNO Change Name
- 7 PQRS Change Passcode
- 5 JKL Distribution Lists
- 2 ABC Call Schedule Options
- 8 TUV Tutorial
- 9 WXYZ Exit to Main Menu
- 3 DEF Fax Delivery Options

## FAX DELIVERY

- 7 PQRS Retrieve unplayed fax messages
- 6 MNO Personal fax telephone number
- 2 ABC Fax cover page options
- 3 DEF Enable/disable auto fax delivery
- 9 WXYZ Exit options menu