

The Ericom PowerTerm Windows-Based Terminal (WBT) V8.1 CE is a fully functional terminal emulator. It enables you to connect to a single or to multiple hosts via both network and serial or modem connections. This quick reference gives only basic connection properties. To use the other functions of this emulator, go to <http://www.wyse.com/products/winterm/reference/3series/index.asp> for the complete User's Manual.

Connections

Connect to the Host

Click Connect, or double-click on the session name to establish the connection.

Exit the Host:
(An exit while connected to the host will end the connection.)

Select File > Exit, or Press <ALT> + <X> on the keyboard.

The following table lists the Toolbar Buttons and their functions:

	Suspends and resumes communication with the host.
	Cuts the selected text.
	Copy to Clipboard.
	Paste from Clipboard.
	Prints selected text from the history buffer or the entire contents of the work area.
	Prints incoming data as it is displayed on the screen. Click the icon again and the automatic printing stops.
	Records manual operations in script form. Click the icon again and the script recording stops.
	Change to 80 Columns.
	Change to 132 Columns.
	Displays the Terminal Setup dialog box.
	Keyboard Mapping.
	Displays and closes the Power Pad.
	Help Contents.
	Opens the Session Manager dialog box.
	Session Manager Button.

Toolbar

The Ericom PowerTerm Windows-Based Terminal (WBT) V8.1 CE is a fully functional terminal emulator. It enables you to connect to a single or to multiple hosts via both network and serial or modem connections. This quick reference gives only basic connection properties. To use the other functions of this emulator, go to <http://www.wyse.com/products/winterm/reference/3series/index.asp> for the complete User's Manual.

Connections

Connect to the Host

Click Connect, or double-click on the session name to establish the connection.

Exit the Host:
(An exit while connected to the host will end the connection.)

Select File > Exit, or Press <ALT> + <X> on the keyboard.

The following table lists the Toolbar Buttons and their functions:

	Suspends and resumes communication with the host.
	Cuts the selected text.
	Copy to Clipboard.
	Paste from Clipboard.
	Prints selected text from the history buffer or the entire contents of the work area.
	Prints incoming data as it is displayed on the screen. Click the icon again and the automatic printing stops.
	Records manual operations in script form. Click the icon again and the script recording stops.
	Change to 80 Columns.
	Change to 132 Columns.
	Displays the Terminal Setup dialog box.
	Keyboard Mapping.
	Displays and closes the Power Pad.
	Help Contents.
	Opens the Session Manager dialog box.
	Session Manager Button.

Toolbar

The Ericom PowerTerm Windows-Based Terminal (WBT) V8.1 CE is a fully functional terminal emulator. It enables you to connect to a single or to multiple hosts via both network and serial or modem connections. This quick reference gives only basic connection properties. To use the other functions of this emulator, go to <http://www.wyse.com/products/winterm/reference/3series/index.asp> for the complete User's Manual.

Connections

Connect to the Host

Click Connect, or double-click on the session name to establish the connection.

Exit the Host:
(An exit while connected to the host will end the connection.)

Select File > Exit, or Press <ALT> + <X> on the keyboard.

The following table lists the Toolbar Buttons and their functions:

	Suspends and resumes communication with the host.
	Cuts the selected text.
	Copy to Clipboard.
	Paste from Clipboard.
	Prints selected text from the history buffer or the entire contents of the work area.
	Prints incoming data as it is displayed on the screen. Click the icon again and the automatic printing stops.
	Records manual operations in script form. Click the icon again and the script recording stops.
	Change to 80 Columns.
	Change to 132 Columns.
	Displays the Terminal Setup dialog box.
	Keyboard Mapping.
	Displays and closes the Power Pad.
	Help Contents.
	Opens the Session Manager dialog box.
	Session Manager Button.

Toolbar

Create a Connection Entry:

Right-click anywhere on the screen and click on Add Connection. The New Connection dialog box displays.

Select Ericom PowerTerm - Terminal Emulator.

Click OK. The Connection Properties dialog box displays.

Select the following properties:

Session Type	COM
VT Terminals	VT 220-7
Wait Before Connect (Sec)	15
Connection Name	"VT220-7"

Click the Properties button.

Set the following Comm properties:

Baud Rate	19200	Note: Some sites may still use 9600 baud.
Parity	8/None	
Stop Bit	1	
Flow Control	None	

Click OK. The icon is added to the desktop.

Connections

Create a Connection Entry:

Right-click anywhere on the screen and click on Add Connection. The New Connection dialog box displays.

Select Ericom PowerTerm - Terminal Emulator.

Click OK. The Connection Properties dialog box displays.

Select the following properties:

Session Type	COM
VT Terminals	VT 220-7
Wait Before Connect (Sec)	15
Connection Name	"VT220-7"

Click the Properties button.

Set the following Comm properties:

Baud Rate	19200	Note: Some sites may still use 9600 baud.
Parity	8/None	
Stop Bit	1	
Flow Control	None	

Click OK. The icon is added to the desktop.

Connections

Create a Connection Entry:

Right-click anywhere on the screen and click on Add Connection. The New Connection dialog box displays.

Select Ericom PowerTerm - Terminal Emulator.

Click OK. The Connection Properties dialog box displays.

Select the following properties:

Session Type	COM
VT Terminals	VT 220-7
Wait Before Connect (Sec)	15
Connection Name	"VT220-7"

Click the Properties button.

Set the following Comm properties:

Baud Rate	19200	Note: Some sites may still use 9600 baud.
Parity	8/None	
Stop Bit	1	
Flow Control	None	

Click OK. The icon is added to the desktop.

Connections

The following table lists some of the default hot keys:

Alt F4	Exit
Ctrl Up Arrow	Scroll up one line
Ctrl Down Arrow	Scroll down one line
Ctrl Home	Scroll to the beginning of the history buffer
Ctrl End	Scroll to the end of the history buffer
Ctrl Page Up	Scroll up one page
Ctrl Page Down	Scroll down one page

Terminal Setup

Click Terminal > Setup.

The Terminal Setup screen displays.

General Tab Settings:

Set the following Properties:

Terminal ID	VT 220
UPS Set	DEC Multinational
Cursor Keys	Normal
Keypad	Numeric
Cursor Coupling	Page
Status Line	None

Check the following:

Online
Use 8 Bit Data Characters

Display Tab Settings:

Set the following Properties:

General:	Ctrl Character:
Autowrap Characters	Interpret
History Scroll Bar	Dimension:
Cursor Ruler:	80 Columns
Crosshair	Lines per Screen = 25
Cursor:	Scrolling:
Block	Jump
Blinks	Unlimited
Visible	

Check the following:

Enable Soft Fonts

Keyboard Tab Settings:

Set the following Properties:

Backspace Key Sends:	
Delete	
Answerback Message:	
WYS30	

Check the following:

Auto Answerback

Preferences Tab Settings:

Set the following Properties:

History Buffer:	
1000K (1.0MB)	

On PowerTerm Exit:

Save Terminal Setup
Confirm Disconnect Session

The following table lists some of the default hot keys:

Alt F4	Exit
Ctrl Up Arrow	Scroll up one line
Ctrl Down Arrow	Scroll down one line
Ctrl Home	Scroll to the beginning of the history buffer
Ctrl End	Scroll to the end of the history buffer
Ctrl Page Up	Scroll up one page
Ctrl Page Down	Scroll down one page

Terminal Setup

Click Terminal > Setup.

The Terminal Setup screen displays.

General Tab Settings:

Set the following Properties:

Terminal ID	VT 220
UPS Set	DEC Multinational
Cursor Keys	Normal
Keypad	Numeric
Cursor Coupling	Page
Status Line	None

Check the following:

Online
Use 8 Bit Data Characters

Display Tab Settings:

Set the following Properties:

General:	Ctrl Character:
Autowrap Characters	Interpret
History Scroll Bar	Dimension:
Cursor Ruler:	80 Columns
Crosshair	Lines per Screen = 25
Cursor:	Scrolling:
Block	Jump
Blinks	Unlimited
Visible	

Check the following:

Enable Soft Fonts

Keyboard Tab Settings:

Set the following Properties:

Backspace Key Sends:	
Delete	
Answerback Message:	
WYS30	

Check the following:

Auto Answerback

Preferences Tab Settings:

Set the following Properties:

History Buffer:	
1000K (1.0MB)	

On PowerTerm Exit:

Save Terminal Setup
Confirm Disconnect Session

The following table lists some of the default hot keys:

Alt F4	Exit
Ctrl Up Arrow	Scroll up one line
Ctrl Down Arrow	Scroll down one line
Ctrl Home	Scroll to the beginning of the history buffer
Ctrl End	Scroll to the end of the history buffer
Ctrl Page Up	Scroll up one page
Ctrl Page Down	Scroll down one page

Terminal Setup

Click Terminal > Setup.

The Terminal Setup screen displays.

General Tab Settings:

Set the following Properties:

Terminal ID	VT 220
UPS Set	DEC Multinational
Cursor Keys	Normal
Keypad	Numeric
Cursor Coupling	Page
Status Line	None

Check the following:

Online
Use 8 Bit Data Characters

Display Tab Settings:

Set the following Properties:

General:	Ctrl Character:
Autowrap Characters	Interpret
History Scroll Bar	Dimension:
Cursor Ruler:	80 Columns
Crosshair	Lines per Screen = 25
Cursor:	Scrolling:
Block	Jump
Blinks	Unlimited
Visible	

Check the following:

Enable Soft Fonts

Keyboard Tab Settings:

Set the following Properties:

Backspace Key Sends:	
Delete	
Answerback Message:	
WYS30	

Check the following:

Auto Answerback

Preferences Tab Settings:

Set the following Properties:

History Buffer:	
1000K (1.0MB)	

On PowerTerm Exit:

Save Terminal Setup
Confirm Disconnect Session



1st Edition (December 19, 2006)
© Copyright 2006 Astra Intecom Inc.
All rights reserved.

Address comments to:

Aastra Intecom
Customer Information Group Manager, MS 1N
2811 Internet Boulevard
Frisco, TX 75034-1851
Telephone: 469.365.3237

Email: techpubs@aastraintecom.com



1st Edition (December 19, 2006)
© Copyright 2006 Astra Intecom Inc.
All rights reserved.

Address comments to:

Aastra Intecom
Customer Information Group Manager, MS 1N
2811 Internet Boulevard
Frisco, TX 75034-1851
Telephone: 469.365.3237

Email: techpubs@aastraintecom.com



1st Edition (December 19, 2006)
© Copyright 2006 Astra Intecom Inc.
All rights reserved.

Address comments to:

Aastra Intecom
Customer Information Group Manager, MS 1N
2811 Internet Boulevard
Frisco, TX 75034-1851
Telephone: 469.365.3237

Email: techpubs@aastraintecom.com