


MITEL

5550 IP Console



5550 IP Console Main Window

- 1 **Menu** – access the drop-down menus.
- 2 **Tools** – click the icons to access tools.
- 3 **Console Status** – view the console and system states.
- 4 **Directories** – access the Busy Lamp Field and Phone Book directories.
- 5 **Queued Calls** – manage incoming, held, transferred, and parked calls.
- 6 **Source/Destination** – view caller and called-party information.
- 7 **Call Waiting/Line** – view numerical and color-coded call-waiting indicators and line information.
- 8 **Softkeys area** – view softkey labels.
- 9 **Response area** – view date and time and system warnings.



it's about **YOU**

M Mitel (design) is a registered trademark of Mitel Networks Corporation. © 2006, Mitel Networks Corporation. All other products and services are the trademarks of their respective holders. All rights reserved.

Note: For additional information about all the 5550 IP Console call-handling tools and features, refer to the 5550 IP Console Help. To access the Help, select **Help** from the main Menu area, then select **Contents**.

Answer a Call

- Lift the handset (optional).
- Press **Answer** on the keypad
OR
- Double-click the call in the **Incoming Calls** display
OR
- Press a **[F1]** to **[F7]** softkey
OR
- Press **Retrieve**, then the incoming call ID digit (1-6).

Transfer a Call

- Dial the destination number.
- Press **Release** on the keypad to complete the transfer and disconnect the call from the console.

Recover a Call

- Press **Recover** immediately after completing the transfer
OR
- Double-click the call in the **Transferred Calls** display.

Place a Call on Hold

- Inform the caller that you are placing the call on hold.
- Press **Hold** on the keypad.

Park a Call

- Press or click **[Park Call]** and observe that the Park Call form replaces the *Destination* area.
- Dial the desired extension number.

NOTE: You can also use the **[Park At]** softkey in the Directories panel. Refer to the 5550 IP Console Help for detailed instructions.

Retrieve an Incoming, Held, Transferred, or Parked Call

- Press **Retrieve**, then the call ID digit (1-9) of the call you want to retrieve
OR
- Double-click the call in the displayed **Queued Calls** tab.

Answer a Recall

- Press the **[Recall]** softkey
OR
- Press **Answer** on the keypad.
- Ask if the caller wants to continue waiting or wishes to be ring another extension.

Transfer a Recall to Voice Mail

- Press **VoiceMail** on the keypad to transfer a recall to the extension's voice mailbox.

Conference a Call

- With the two parties connected to the console — one in the Source area and the other in the Destination area — press the **[Conference]** softkey.

To split a conference to speak privately to either caller

- Press either **[Source]** or **[Destination]** softkey.

To add more parties to a conference

- Dial the number of the next party.
- Press the **[Conference]** softkey.


If the line is busy or unanswered or the person is unavailable

- Press **Cancel** on the keypad to reconnect to the conference. You may continue adding more parties to the conference.

To release the conference from the console

- Press **Release** on the keypad.

NOTE: Once you release the conference, you cannot re-enter it.



EE0509

About the Console Keypad

The console keypad is used for dialing, call processing, and accessing system features.

You can adjust the slope of the keypad and detach or from (or attach it to) the handset cradle.

You can also use the console keypad to maximize and minimize the Main Window Directories and Queued Calls panels.

Use Volume to increase (+) or decrease (-) the ringer and earpiece volume in the handset or headset. Mute enables/disables the microphone in the headset or handset.

To maximize/minimize a panel

1. Press the associated keypad key, for example, Phone Book, or Incoming Calls.

If the panel was maximized on screen at the first keypad press, it is minimized.

If the panel was minimized on screen at the first keypad press, it is maximized.

2. Press the associated key to toggle between the maximized and minimized views.

Using the Console Keypad

Fixed Function Keys

Fixed Function keys are used to answer and manage calls.

ANSWER	Answer calls on a “first-come first served” basis (the default) or according to the priorities assigned using the Options command in the Tools menu
RELEASE	Complete a call transfer
HOLD	Put a call on hold
RECOVER	Return a call you transferred to the wrong extension to the console
RETRIEVE	Answer an incoming call, or reconnect to a held, transferred, or parked call.
CANCEL	Clear misdialed numbers

Programmable Firmkeys

Programmable keys provide customized access to the following console features and system services.

Some of the features listed below are programmed for you by default; others are optional and may not be labeled on your console keypad. Refer to the *5550 IP Console Help* for details.

Default Firmkeys

Scratch Pad	Phone Book
Bulletin Board	Busy Lamp Field (BLF)
Voice Mail	Incoming Calls
Pager	Calls on Hold
Message Waiting	Transferred Calls
Tones	Parked Calls

Optional Firmkeys

Emergency Call	Third Party App
Guest Services	Trunk Status
Help	Unassigned

